




The **RF** Experts

- Easy to operate and field ready for first-time, occasional and experienced users.
- FDR (Frequency Domain Reflectometry) measurement method results in a highly reliable assessment of the health of critical components in your system; ultimately providing a "heads-up" before a failure occurs.
- Fault location or DTF mode indicates VSWR or Return Loss levels at each point along the cable and antenna system length.
- Cable Loss function measures insertion loss of the cable system over a given frequency range.
- Units cover frequency ranges of 300 kHz-200 MHz,1-4500 MHz and 1-6000 MHz.
- USB communication port for connection to storage device and battery charging.
- Three Year Warranty!!
- Includes Bird RF Meter App.:



MEASUREMENT CAPABILITY

Fast swept measurement.

Seven user-selectable trace capture options: 51,101,201,401,801,1601 or 3201 data points per sweep.

Adjustable pass/fail limit with visual indicator.

16GB of internal flash memory for storing thousands of traces and setups.

X and Y scales and units are user adjustable.

Six markers for either direct or difference measurements.

Can also measure relative to limit line or recalled trace.

Measurement hold to temporarily store a trace.

Frequency can be set using either Start/Stop or Center/Span frequencies.

Measurement can be Return Loss [dB], Cable Loss [dB], VSWR [ratio], DTF VSWR [ratio] or DTF Return Loss [dB].

Measurement units can be Return Loss [dB] or VSWR [ratio].



APPLICATIONS

Worldwide Cellular, PCS/DCS, CDMA, GSM, LTE Protocols, 3G, Broadcast, Government, Tactical Military, Microwave, Paging, Public Safety, Trunking, WLAN, TETRA, WLL.



SiteHawk Analyzer sk-200-тс, sk-4500-тс, sk-6000-тс

	SPECIF	FICATIONS ————		
SK-4500-TC	300 kHz - 200 MHz 1 MHz - 4500 MHz 1 MHz - 6000 MHz	Dimensions (L×W×H)		7.2 x 3.8 x 1.9 (in) 182 x 95 x 46.5 (mm) 7.7 x 3.6 x 2.4 (in) 195 x 90 x 60 (mm)
		Weight		1.98 (lbs) 0.9 (kg)
Frequency Resolution	-10dBm ±.5 dB	Screen Size & R	esolution	5.5", 720p
Reflect Amplitude Accuracy	-10dbiii ±.3 db	Corrected Directivity Maximum Input Voltage		> 38 dB
-15 dB to 0 dB				50V
-25 dB to -15 dB -35 dB to -25 dB		Operation Ten	nperature	14°F to 131°F -10°C to +55°C
Trace Noise Magnitude (IFBW 1kHz)	0.05 dB rms	Storage Ten	nperature	-40°F to 176°F
Measurement Speed	1ms / data point			-40°C to +80°C
Measurement Points	51 to 3201	Battery Charging Temperature		
Measure Bandwidth	100 Hz to 30kHz		•	
Temperature Stability	0.01 dB/°F 0.02 dB/°C	Immunity to Interferin	. ,	Thousands of Trace and Setups +13dBm
Return Loss Measurement Range Resolution		CE		Standard EN 61326-1:2006
VSWR Measurement Range	1.0 to 65.0			
Cable Loss Measurement Range	0 dB to 30 dB	Battery SK-200-TC		4 Hrs Typical Operating Time
DTF Range	0 to 5000 (ft) 0 to 1500 (m)		SK-4500-TC, SK-6000-TC Battery Charge Time	
Test Port Connector Impedance		Power Measurement		
Connector	Micro USB B, USB 2.0	Compatible With		
Languages	English, Chinese, Spanish			
Recommended Calibration Interval	3 years			
STANDARD ACCESSORIES PROVIDED - SK-200-TC STANDARD ACCESSORIES PROVIDED - SK-4500-TC, SK-6				ED - SK-4500-TC, SK-6000-TC
SK-CAL-MN-C Calibration Combo		SK-CAL-MN-C6	Calibration Combo	
SK-TP-112 Stylus		SK-TP-112		
			31,143	
5B2229-510H-3 AC ADAPTER (5	5 Vdc Ouput)	SK05T-1200300Z		r (12 Vdc Ouput)
			AC Adapte	·
5B2229-510H-3 AC ADAPTER (5 7002A218-2 Hard Carrying		SK05T-1200300Z	AC Adapte Hard Carry	·
5B2229-510H-3 AC ADAPTER (5 7002A218-2 Hard Carrying 5A2653-3R5NL4 USB Interface C SK-TC-MNFN-1M RF Cable, 1.0 m	Case Cable, Power, 1 meter long neter long	SK05T-1200300Z 7002A218-2	AC Adapte Hard Carry RF Cable, 1 Instruction	ing Case
5B2229-510H-3 AC ADAPTER (5 7002A218-2 Hard Carrying 5A2653-3R5NL4 USB Interface (5 SK-TC-MNFN-1M RF Cable, 1.0 m 920-SK-4000 Instruction Ma	Case Cable, Power, 1 meter long neter long nual	SK05T-1200300Z 7002A218-2 SK-TC-MNFN-1M 920-SK-4500	AC Adapte Hard Carry RF Cable, 1 Instruction	ing Case .0 meter long Manual (SK-4500-TC) Manual (SK-6000-TC)
5B2229-510H-3 AC ADAPTER (5 7002A218-2 Hard Carrying (5 5A2653-3R5NL4 USB Interface (6 SK-TC-MNFN-1M RF Cable, 1.0 m 920-SK-4000 Instruction Ma 7002A219-1 Soft Carrying (6	Case Cable, Power, 1 meter long neter long nual	SK05T-1200300Z 7002A218-2 SK-TC-MNFN-1M 920-SK-4500 920-SK-6000	AC Adapte Hard Carry RF Cable, 1 Instruction Instruction Soft Carryi	ing Case .0 meter long Manual (SK-4500-TC) Manual (SK-6000-TC)
5B2229-510H-3 AC ADAPTER (5 7002A218-2 Hard Carrying 5A2653-3R5NL4 USB Interface C SK-TC-MNFN-1M RF Cable, 1.0 m 920-SK-4000 Instruction Ma 7002A219-1 Soft Carrying C 5A2745-1 USB Drive	Case Cable, Power, 1 meter long neter long nual Case	SK05T-1200300Z 7002A218-2 SK-TC-MNFN-1M 920-SK-4500 920-SK-6000 7002A219-1	AC Adapte Hard Carry RF Cable, 1 Instruction Instruction Soft Carryi USB Drive	ing Case .0 meter long n Manual (SK-4500-TC) n Manual (SK-6000-TC) ng Case
5B2229-510H-3 AC ADAPTER (5 7002A218-2 Hard Carrying 5A2653-3R5NL4 USB Interface C SK-TC-MNFN-1M RF Cable, 1.0 m 920-SK-4000 Instruction Ma 7002A219-1 Soft Carrying C 5A2745-1 USB Drive	Case Cable, Power, 1 meter long neter long nual	SK05T-1200300Z 7002A218-2 SK-TC-MNFN-1M 920-SK-4500 920-SK-6000 7002A219-1 5A2745-1	AC Adapte Hard Carry RF Cable, 1 Instruction Instruction Soft Carryi USB Drive USB Adapt	ing Case .0 meter long n Manual (SK-4500-TC) n Manual (SK-6000-TC) ng Case
5B2229-510H-3 AC ADAPTER (5 7002A218-2 Hard Carrying 5A2653-3R5NL4 USB Interface C SK-TC-MNFN-1M RF Cable, 1.0 m 920-SK-4000 Instruction Ma 7002A219-1 Soft Carrying C 5A2745-1 USB Drive 5A2653-0R5NL5 Micro USB mal	Case Cable, Power, 1 meter long neter long nual Case	SK05T-1200300Z 7002A218-2 SK-TC-MNFN-1M 920-SK-4500 920-SK-6000 7002A219-1 5A2745-1 SK-CONN-OTG-2	AC Adapte Hard Carry RF Cable, 1 Instruction Instruction Soft Carryi USB Drive USB Adapt Battery	ing Case .0 meter long n Manual (SK-4500-TC) n Manual (SK-6000-TC) ng Case
5B2229-510H-3 AC ADAPTER (5 7002A218-2 Hard Carrying 5A2653-3R5NL4 USB Interface (6 SK-TC-MNFN-1M RF Cable, 1.0 m 920-SK-4000 Instruction Ma 7002A219-1 Soft Carrying (6 5A2745-1 USB Drive 5A2653-0R5NL5 Micro USB mal 15 cm long	Case Cable, Power, 1 meter long neter long nual Case	SK05T-1200300Z 7002A218-2 SK-TC-MNFN-1M 920-SK-4500 920-SK-6000 7002A219-1 5A2745-1 SK-CONN-OTG-2 SK-BTY-7468 OPTIONAL ACCESSORIES	AC Adapte Hard Carry RF Cable, 1 Instruction Instruction Soft Carryi USB Drive USB Adapt Battery	ing Case .0 meter long n Manual (SK-4500-TC) n Manual (SK-6000-TC) ng Case
5B2229-510H-3 AC ADAPTER (5 7002A218-2 Hard Carrying 5A2653-3R5NL4 USB Interface (6 SK-TC-MNFN-1M RF Cable, 1.0 m 920-SK-4000 Instruction Ma 7002A219-1 Soft Carrying (6 5A2745-1 USB Drive 5A2653-0R5NL5 Micro USB mal 15 cm long	Case Cable, Power, 1 meter long neter long nual Case	SK05T-1200300Z 7002A218-2 SK-TC-MNFN-1M 920-SK-4500 920-SK-6000 7002A219-1 5A2745-1 SK-CONN-OTG-2 SK-BTY-7468 OPTIONAL ACCESSORIES	AC Adapte Hard Carry RF Cable, 1 Instruction Instruction Soft Carryi USB Drive USB Adapt Battery	ing Case .0 meter long n Manual (SK-4500-TC) n Manual (SK-6000-TC) ng Case eer







